



Dexter WCAD20KCS-10 (T300) Water Inlet Parts



[Dexter Commercial Dexter WCAD20KCS-10 \(T300\) Washer Parts](#) Parts Diagram Water Inlet Parts
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9379-183-003			Valve, Water Inlet (dual outlet) (see Water Inlet Valve Breakdown for individual parts)
*	9545-008-026			Screw, Vault Mtg
"	8640-399-009			Nut, Spring
4	9610-001-001			Vaccum Breaker ALL
*	9029-065-001			Bracket, Vacuum Breaker
"	9545-008-026			Screw, Vault Mtg
3	9550-186-001			Shield over Water Valves Plastic
5	9242-458-001			Hose, Vacuum Breaker to tub
*	8654-117-009			Clamp, Tub End
8	9242-453-020	9242-453-020P		Hose - 18"

7	9242-453-015	9242-453-015P	Fill Hose
6	9242-453-016	9242-453-016P	Fill Hose 14.5"
*	8654-117-015		Clamp, Pressure Switch Hose
"	8654-117-018		Clamp, Hose overflow to drain
"	9475-002-002		Flow Restrictors (in dispenser)
"	5198-211-004		Circuit Breaker (optional)
14	9200-001-002		Fuseholder
15	8636-018-001		Fuse - 1.5 A.
16	9242-468-001		Hose Tub to Drain Valve
17	8654-117-014		Clamp, Hose to Vacuum Breaker

the laundry company®

the laundry company®

the laundry company®