
Dexter WCAD20KCS-12 (T300) Water Inlet Parts



<u>Dexter Commercial Dexter WCAD20KCS-12 (T300) Washer Parts Parts Diagram Water Inlet Parts</u> <u>Click on the part number to view part</u>

			_	
Item	Original Part Number	Replaced By	Status	Part Description
1	9379-183-003			Valve, Water Inlet (dual outlet) (see Water Inlet Valve Breakdown for individual parts)
*	<u>9545-008-026</u>			Screw, Vault Mtg
"	8640-399-009			Nut, Spring
4	<u>9610-001-001</u>			Vaccum Breaker ALL
*	9029-065-001			Bracket, Vacuum Breaker
"	<u>9545-008-026</u>			Screw, Vault Mtg
3	<u>9550-186-001</u>			Shield over Water Valves Plastic
5	9242-458-001			Hose, Vacuum Breaker to tub
*	8654-117-009			Clamp, Tub End
8	9242-453-020	9242-453-020P		Hose - 18"

7	9242-453-015	<u>9242-453-015P</u>	Fill Hose
6	9242-453-016	<u>9242-453-016P</u>	Fill Hose 14.5"
*	<u>8654-117-015</u>		Clamp, Pressure Switch Hose
"	8654-117-018		Clamp, Hose overßow to drain
ıı ı	9475-002-002		Flow Restrictors (in dispenser)
"	5198-211-004		Circuit Breaker (optional)
14	9200-001-002		Fuseholder
15	<u>8636-018-001</u>		Fuse - I.5 A.
16	9242-468-001		Hose Tub to Drain Valve
17	<u>8654-117-014</u>		Clamp, Hose to Vacuum Breaker

the laundry company

the laundry company'