

Dexter WCAD20KCS-12SZ (T350) Cabinet And Front Panel Group Parts



[Dexter Commercial Dexter WCAD20KCS-12SZ \(T350\) Washer Parts](#) Parts Diagram Cabinet And Front Panel Group Parts
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9454-828-001			Panel, Right Side-stainless
"	9545-828-002		Not Available	Panel, Left Side - stainless
2	9545-018-018			Screw, (Side Panel to Base)
"	8640-414-006			Nut, Hex 1/4-20 UNC
*	0904-904-001		Not Available	Pad-Foam, Side Panel
3	9942-033-008			Vault Assembly, Coin
*	9545-008-026			Screw, Vault Mtg
4	9119-031-001			Coin Chute Assy.
*	9545-008-001			Screw 10-32 x 1/4
"	9029-066-001			Bracket, Side Panel under front panel
"	8640-413-002			Nut, Hinge to Door

"	9545-008-026		Screw, Vault Mtg
5	9989-522-001		Panel, Control (Mounts Name-plate)
*	9545-008-026		Screw, Vault Mtg
6	9412-156-001		Nameplate Decal, Control Panel (Blue)
"	9412-169-001		Nameplate Decal, Control Panel (Black)
7	8502-726-001		Label Nameplate RH (STOP)
"	8502-744-001		Label-Nameplate, RH (Black)
*	9452-725-001		Stop Button Mounting Plate
8	9732-223-001		Switch Assembly Emergency Stop (includes wire harness)
9	9021-016-001		Acceptor, Coin-Optical switch w/harness
*	9486-149-001		Retainer-Dual Coin Acceptor
"	9545-053-002		Screw
10	9454-781-001		Panel Assy, Front
11	9059-063-004	9059-063-004P	Edge protector 18
*	9545-008-031		Screw
"	8640-399-005		Nut, Spring- To Control Panel 10/32
12	9545-008-014		Screw, FLHDCR, 10B x 1
13	8641-585-001		Lockwasher
*	8640-399-008		Nut, Spring-To Front Panel
14	8502-723-001		Label, Door Opening
"	8502-742-001		Label, Door Opening-Black
15	8502-722-002		Label Warning Risk of Injury
"	8502-741-001		Label, Warning Risk of Injury-Black
16	9960-286-001		Door, Lower Service (includes handle & Rivits)
17	9244-086-001		Handle (bumper guard)
*	9491-009-003	Not Available	Rivet
18	9545-008-014		Screw, FLHDCR, 10B x 1
19	8641-585-001		Lockwasher
*	8640-399-008		Nut, Spring-To Front Panel
20	9807-099-001		Box Assembly Coin Vault ESD W/lock & Key Chrome
"	9807-099-003		Coin Box Assy, Black Small
21	9989-498-002		Panel Top, Assembly (includes catch)
*	9086-017-001		Catch, Top Panel
"	8638-190-009		Pop Rivet for mtg catch
22	8650-012-003		Lock and Key, Control
*	6292-006-007		Key
"	9095-038-001		Cam, Lock-Top
"	8640-426-001		Nut, 9/32 - 28 Hex
"	8641-581-008		Washer, Spacer- Thick
23	9545-008-023		Screw, Guide
24	9355-001-001		Locator Panel

25	9467-024-001	Post Locator Top
*	8640-411-003	Nut, Switch Locking
26	9108-095-005	Door, Dispenser
27	9467-025-001	Post, Door Mounting
*	9451-191-001	Pin, Plain
"	9545-045-002	Screw, Mtg (top)
28	9122-005-004	Dispenser Soap
29	9206-416-001	Gasket, Dispenser
*	8640-399-007	Nut Spring SS
30	9545-008-012	Screw, Disp. Mtg
*	9475-002-002	Flow Restrictors (in dispenser)
"	9456-041-007	Plastic Plug 1 1/2"(inside cylinder)
31	9029-066-001	Bracket, Side Panel under front panel