


Dexter WCAD20KCS-12SZ (T350) Loading Door Parts



Dexter Commercial Dexter WCAD20KCS-12SZ (T350) Washer Parts Parts Diagram Loading Door Parts
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	9960-273-001	9960-273-001P		18# Door Assy.
1	9487-264-001			Loading Door, Ring
2	9206-411-001	9206-411-002		Gasket, Loading Door
3	9635-018-001			Window, Loading Door
*	9913-134-003	9913-134-003P		Shaft assy.
4	9537-195-002			Shaft, Door Locking
5	9095-040-002			Cam, Locking
6	9451-181-005			Pin, Groove (1 1/4)
7	9451-181-004			Pin, Dowel
	8649-031-002			Retaining Ring (c-clip)
8	9534-360-002			Spring, Lock Cam

9	9244-080-003		Handle, Door
11	9451-181-006		Pin, Door Handle (groove)
*	9545-014-009		Screw, Hinge Mtg 5/16" x 3/4"
"	8641-582-009		Lockwasher, Circuit Board
"	9552-036-001		Shim, Loading Door Hinge, Thin
10	9955-029-002		Door Hinge Assembly Mounts to Tub Front
13	9545-056-001		Screw, Loading Door Mtg (5/16" TF)
*	9059-063-004	9059-063-004P	Edge protector 18
"	8640-413-002		Nut, Hinge to Door
"	9627-791-003		Wiring Harness doorlock safety switch
12	9938-040-002		Loading Door Hinge Clamp (mounts to door ring)
*	9079-122-003		Loading Door Hinge Clamp (No Hinge Switch Pin) (NEW Style)
14	9950-059-001		Masking Assembly
*	8640-413-002		Nut, Hinge to Door
15	9801-089-001		Switch Assembly Complete Door Closure
16	9041-087-001	Not Available	Switch Box
17	8220-063-026		Wire Assembly Door Close Switch, BLK 17"
18	8220-063-025		Wire Assembly Door Close Switch, Red 17"
19	9053-067-003		Bushing Insulating
20	8640-401-001		Nut, Special Twin
*	9545-020-001		Screw, Switch Mtg
"	8640-413-002		Nut, Hinge to Door
"	9008-004-001		Actuator, Switch- Lower
21	9539-461-007		Switch-Micro

the laundry company[®]