


Dexter WCAD25KCS-12 (T-400) Cabinet And Front Panel Group



Dexter [Commercial Dexter WCAD25KCS-12 \(T-400\) Washer Parts](#) Parts Diagram Cabinet And Front Panel Group
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------------|-------------------------------|--------|---|
| 1 | 9454-656-001 | 9454-829-001 | | Panel, Side (Left or Right) - stainless |
| 2 | 9545-018-013 | | | Screw, (Side Panel to Base) |
| " | 8640-414-006 | | | Nut, Hex 1/4-20 UNC |
| 3 | 9029-066-001 | | | Bracket, Side Panel under front panel |
| * | 8640-413-002 | | | Nut, Hinge to Door |
| " | 9545-008-024 | | | Screw HX Head Tapping (Mounts bracket housing to dryer) |
| 4 | 9454-659-001 | | | Panel Assy, Front |
| * | 9452-725-001 | | | Stop Button Mounting Plate |
| 5 | 9059-063-002 | 9059-063-002P | | Edge protector |

| | | | |
|----|------------------------------|------------------------------|---|
| * | 9545-008-024 | | Screw HX Head Tapping (Mounts bracket housing to dryer) |
| " | 8640-399-005 | | Nut, Spring- To Control Panel 10/32 |
| 6 | 9545-008-014 | | Screw, FLHDCR, 10B x 1 |
| " | 8641-585-001 | | Lockwasher |
| * | 8640-399-008 | | Nut, Spring-To Front Panel |
| 7 | 8502-723-001 | | Label, Door Opening |
| 8 | 9989-497-001 | | Panel, Control (Mounts Nameplate) |
| * | 9545-008-026 | | Screw, Vault Mtg |
| 9 | 9412-137-001 | | Nameplate Decal, Control Panel |
| 10 | 9989-498-003 | | Panel Top |
| 11 | 8650-012-003 | | Lock and Key, Control |
| -- | 9086-017-001 | | Catch, Top Panel |
| " | 9545-008-023 | | Screw, Guide |
| 12 | 9108-097-001 | 9960-286-002 | Door, Lower Service (includes handle & Rivits) |
| 13 | 9244-081-002 | 9244-086-002 | Handle (bumper guard) |
| * | 9545-045-010 | | Screw |
| 14 | 9545-008-014 | | Screw, FLHDCR, 10B x 1 |
| " | 8641-585-001 | | Lockwasher |
| * | 8640-399-008 | | Nut, Spring-To Front Panel |
| 15 | 9108-095-005 | | Door, Dispenser |
| 20 | 9451-191-001 | | Pin, Plain |
| 21 | 9467-025-001 | | Post, Door Mounting |
| 22 | 9545-045-002 | | Screw, Mtg (top) |
| 23 | 9545-008-012 | | Screw, Disp. Mtg |
| 16 | 9732-122-010 | Not Available | SS Coin Box Assy, Coin |
| 17 | 9021-001-010 | | Acceptor, Coin |
| 18 | 9456-041-007 | | Plastic Plug 1 1/2Ø-(inside cylinder) |
| 19 | 6292-006-007 | | Key |
| " | 9095-038-001 | | Cam, Lock-Top |
| -- | 8640-426-001 | | Nut, 9/32 - 28 Hex |
| " | 8641-581-008 | | Washer, Spacer- Thick |