
Dexter WCAD30KCS-12 (T-400) Loading Door Hinge



Dexter Commercial Dexter WCAD30KCS-12 (T-400) Washer Parts Parts Diagram Loading Door Hinge Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<u>9955-029-002</u>			Door Hinge Assembly Mounts to Tub Front
2	<u>9781-001-001</u>			Loading Door Hinge Pin
3	<u>9079-122-003</u>			Loading Door Hinge Clamp (No Hinge Switch Pin) (NEW Style)
4	<u>9487-273-001</u>			Masking Ring
5	<u>8220-063-025</u>			Wire Assembly Door Close Switch, Red 17"
9	<u>8220-063-026</u>			Wire Assembly Door Close Switch, BLK 17"
10	<u>9539-492-001</u>			Switch, Door closed Switch (Push Button style)
11	<u>9487-273-001</u>			Masking Ring