Dexter WCAD30KCS-12 (T-400) Loading Door Parts



Dexter Commercial Dexter WCAD30KCS-12 (T-400) Washer Parts Parts Diagram Loading Door Parts
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	9960-274-002	9960-274-002P		Door Assy.
1	9487-265-001			Loading Door, Ring
2	9206-419-001			Gasket, Loading Door
3	9635-016-001			Window, Loading Door
*	9913-134-003	9913-134-003P		Shaft assy.
4	9537-195-002			Shaft, Door Locking
5	9095-040-002			Cam, Locking
6	9451-181-005			Pin, Groove (1 1/4)
7	9451-181-004			Pin, Dowel
	8649-031-002			Retaining Ring (c-clip)
8	9534-360-002			Spring, Lock Cam

9	9244-080-003			Handle, Door
11	9451-181-006			Pin, Door Handle (groove)
*	9545-014-009			Screw, Hinge Mtg 5/16Ó x 3/4Ó
"	8641-582-009			Lockwasher, Circuit Board
"	9552-036-001			Shim, Loading Door Hinge, Thin
10	9955-029-002			Door Hinge Assembly Mounts to Tub Front
13	9545-056-001			Screw, Loading Door Mtg (5/16Ó TF)
*	9059-063-002	9059-063-002P		Edge protector
"	8640-413-002			Nut, Hinge to Door
"	9627-791-003			Wiring Harness doorlock safety switch
12	9938-040-002			Loading Door Hinge Clamp (mounts to door ring)
*	9079-122-003			Loading Door Hinge Clamp (No Hinge Switch Pin) (NEW Style)
14	9950-060-001			Masking Assembly
*	8640-413-002			Nut, Hinge to Door
15	9801-089-001			Switch Assembly Complete Door Closure
16	9041-087-001		Not Available	Switch Box
17	8220-063-026			Wire Assembly Door Close Switch, BLK 17"
18	8220-063-025			Wire Assembly Door Close Switch, Red 17"
19	9053-067-003			Bushing Insulating
20	8640-401-001			Nut, Special Twin
*	9545-020-001			Screw, Switch Mtg
"	8640-413-002			Nut, Hinge to Door
"	9008-004-001			Actuator, Switch- Lower
21	9539-461-007			Switch-Micro

the laundry company®