


Dexter WCAD30KCS-12 (T-400) Transformer, Electrical Filter And Coin Handling



Dexter [Commercial Dexter WCAD30KCS-12 \(T-400\) Washer Parts](#) Parts Diagram Transformer, Electrical Filter And Coin Handling
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	5198-211-002			Circuit Breaker (59 models)
*	8220-061-003		Not Available	Wire Assembly Black / Red (59 models)
"	8220-061-004		Not Available	Wire Assembly Black / Blue (59 models)
"	8220-001-282			Wireasy- Red, 20"
"	8220-065-007			Wireasy- Blk/Blu, 11"
"	8220-065-011		Not Available	Wire Assembly Red (59 models)
"	8507-230-003		Not Available	Instructions-Transform Connect
"	8514-176-001		Not Available	Owners Booklet (59 models)
"	8640-412-005			NUT-HEXKEPS,#8-32

"	8640-413-002		Nut, Hinge to Door
"	8641-582-005		Lock washer, Circuit Board
2	8711-008-002		Transformer-Control
3	8711-009-003		Transformer (59 models)
4	9021-011-001		Coin Acceptor - Elec- tronic (59 models)
5	9627-845-001		Harness for Electronic Coin Acceptor
*	9029-170-001	Not Available	Bracket Terminal/Fil- ter Mounting (59 models)
"	9527-002-002	Not Available	Standoff Twistlock
6	9183-031-002		EMI Line Filter (59 models)
7	9183-040-001	Not Available	EMI Filter 1 ph, 20 Amp (59 models)

