


Dexter WCAD30KCS-12SZ (T-450) Chassis And Drain Parts



Dexter [Commercial Dexter WCAD30KCS-12SZ \(T-450\) Washer Parts](#) Parts Diagram Chassis And Drain Parts
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9945-116-002		Not Available	Base Assy,Frame
2	9930-142-001		Not Available	Outer Tub Assy
*	9869-014-001			Tub and Cylinder Assy.
"	9950-051-004			Ring Assy, Tub Mtg-Front
7	9950-056-002			Ring Assy,Clamp Tub Mtg.- Rear
*	8641-581-018			Washer
25	9242-456-001			Hose, Tub to Drain Valve
26	8654-117-014			Clamp, Hose to Vacuum Breaker
9	9379-187-004			Valve, Drain (includes #2 thru #11)
19	9242-457-001			Hose, Drain Valve to Tube
"	8654-117-014			Clamp, Hose to Vacuum Breaker

*	9545-008-026		Screw, Vault Mtg
11	9915-119-002		Tube Assy, Drain
*	9545-030-002		Screw Tube (Bracket to Base 1/4Bx3/4)
12	9942-449-002	Not Available	Hose, Overflow to drain
8	8641-582-018		Lockwasher
"	8640-425-001		Nut, Hex 5/8-11
*	9552-038-001		Shim, Support Assembly (thin)
18	9242-458-002		Hose, Vacuum Brkr. to Tub
13	9122-005-004		Dispenser Soap
15	9206-416-001		Gasket, Dispenser
*	8640-399-007		Nut Spring SS
"	9242-450-002		Hose, Dispenser to Tub
"	8654-117-008		Clamp, Hose Vent
14	9732-137-003		Back Assy, Tub 2 piece
17	8640-416-005		Nut, Flange Lock
	9242-175-007		Hose, Pressure Switch
"	8654-117-015		Clamp, Pressure Switch Hose

the laundry company®

the laundry company®