


Dexter WCAD30KCS-12SZ (T-450) Gear Motor Door Lock Assembly



[Dexter Commercial Dexter WCAD30KCS-12SZ \(T-450\) Washer Parts](#) Parts Diagram Gear Motor Door Lock Assembly
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|------------------------------|-------------|---------------|-----------------------------------------------------|
| * | 9892-014-001 | | | Actuator Assembly (Includes 1-10, Rod NOT included) |
| 11 | 9545-012-027 | | | Screw Pnhdcr, 10-32 UNFx0 .75 |
| 10 | 9545-031-011 | | | Screw #6 x 5/16" |
| 9 | 9545-044-003 | | | Screw -Hxwshrhdslsems, 6-32 x 3/16 |
| 8 | 9914-137-011 | | | Motor & Gear Train (complete) |
| 7 | 9534-350-001 | | | Spring - Extension |
| 6 | 9586-001-001 | | | Thermoactuator 120 V |
| 5 | 9001-063-001 | | | Arm - Door Lock |
| 4 | 9538-157-021 | | Not Available | Spacer, Plastic |
| 3 | 9029-204-001 | | Not Available | Bracket Slide Lock |

| | | | |
|---|------------------------------|---------------|-----------------------------------|
| 2 | 9985-189-001 | Not Available | Bracket Assy, Slide - Unlock |
| 1 | 9985-190-001 | Not Available | Bracket Assy, Slide Lock Actuator |
| * | 9497-225-012 | | Rod, Door Lock |

the laundry company[®]

the laundry company[®]

the laundry company[®]