





Dexter WCN18AB Door Lock Group

Door Lock Group



51

[Dexter Commercial Dexter WCN18AB Washer Parts](#) Parts Diagram Door Lock Group
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
*	9885-023-001	9885-024-001		Lock Assy, Complete (#1-22)(includes #1 thru #22)
1	9982-284-001			Plate Assy, Door Lock
2	8641-581-030			Washer, Flat
3	9008-005-001			Actuator, Latching Switch
4	9450-002-002			Pawl, Locking
5	8641-569-003			Washer, Spring
6	9487-200-004			Ring, Retaining
8	9029-035-001		Not Available	Bracket, Switch
9	8640-413-002			Nut, Hinge to Door
10	9534-364-002			Spring, Actuating
11	9545-012-020			Screw, Hx. 10-32 x 1 0

12	8640-413-004		Nut, Elastic Stop
13	9534-364-001		Spring, Return
14	9451-193-001		Pin, Guide
15	9487-200-005		Ring, Retaining
16	8641-581-031		Washer
17	9539-461-008		Switch, Latching Sensing
18	9550-169-003		Shield, Switch
19	9545-020-001		Screw, Switch Mtg
20	8640-401-001		Nut, Special Twin
21	9539-461-007		Switch-Micro
22	9008-006-002		Actuator, Switch
23	9545-020-003		Screw 4-40 x 1 1/8"
"	8640-401-001		Nut, Special Twin
"	9451-181-004		Pin, Dowel
*	9552-037-001		Shim, Door Lock, Thin
"	9552-037-002	Not Available	Shim, Door Lock, Thick AR AR
"	9545-018-014		Screw, Lock mtg 1/4"-20 x 3/4"
"	8641-582-007		Lockwasher 1/4
36	9922-011-001	9922-011-001P	Solenoid Assy.
24	9029-073-001		Bracket, (Door Locking Solenoid)
"	9985-169-001		Bracket Assy, Solenoid Slide
25	9536-074-001		Solenoid 120V 60 hz
26	9545-008-001		Screw 10-32 x 1/4
27	9540-033-001	9540-036-001	Stop, Door Lock Solenoid
28	9545-061-001		Screw, Shoulder
29	9586-001-001		Thermoactuator 120 V
30	9545-031-005		Screw
31	9538-157-004		Spacer, Plastic
32	9538-166-004		Spacer, Metal
33a	9545-010-001		Screw, Cross Recessed
*	8640-412-005		NUT-HEXKEPS,#8-32
"	8640-411-003		Nut, Switch Locking
"	8640-413-002		Nut, Hinge to Door
35	9497-225-004		Rod, Pull