

## Dexter WCN25AB Control Panel Group



Dexter Commercial Dexter WCN25AB Washer Parts Parts Diagram Control Panel Group  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">9539-479-009</a>			Switch, Push button (cycle selector)
*	<a href="#">8640-412-005</a>			NUT-HEXKEPS,#8-32
2	<a href="#">3310-041-001</a>			Light, Cycle Control
*	<a href="#">9206-100-001</a>			Gasket, Light
3	<a href="#">3310-042-001</a>			Light, Bleach
4	9020-005-001	<a href="#">9732-258-001</a>		Coin Accum. Kit
*	<a href="#">9627-682-001</a>			Wiring Harness, Accumulator
"	<a href="#">9538-157-005</a>			Short Spacer (between board and shields)
5	<a href="#">9550-174-001</a>			Shield, Circuit Board
*	<a href="#">8640-412-005</a>			NUT-HEXKEPS,#8-32

"	<a href="#">9538-157-003</a>	Spacers, Circuit Board
6	<a href="#">9021-001-010</a>	Acceptor, Coin
7	9732-122-001 <a href="#">9807-099-001</a>	Box Assembly Coin Vault ESD W/lock & Key Chrome
8	<a href="#">9412-076-007</a>	Nameplate, Control Panel (one piece)
*	<a href="#">8640-412-005</a>	NUT-HEXKEPS,#8-32

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>