


Dexter WCN40AB (T600) Control Panel Group



[Dexter Commercial Dexter WCN40AB \(T600\) Washer Parts](#) Parts Diagram Control Panel Group

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	9539-479-009			Switch, Push button (cycle selector)
*	8640-412-005			NUT-HEXKEPS,#8-32
2	3310-041-001			Light, Cycle Control
*	9206-100-001			Gasket, Light
3	3310-042-001			Light, Bleach
4	9020-005-001	9732-258-001		Coin Accum. Kit
*	9627-682-001			Wiring Harness, Accumulator
"	9538-157-005			Short Spacer (between board and shields)
5	9550-174-001			Shield, Circuit Board
*	8640-412-005			NUT-HEXKEPS,#8-32

"	9538-157-003		Spacers, Circuit Board
6	9021-001-010		Acceptor, Coin
7	9732-122-001	9807-099-001	Box Assembly Coin Vault ESD W/lock & Key Chrome
8	9412-076-006		Nameplate, Control Panel
*	8640-412-005		NUT-HEXKEPS,#8-32

the laundry company[®]

the laundry company[®]

the laundry company[®]