

Dexter WCVD25KCS-12 Control Panel All Models



108

Dexter Commercial Dexter WCVD25KCS-12 Washer Parts Parts Diagram Control Panel All Models
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	9989-473-001			Panel, Control (Mounts Nameplate)
"	9989-474-001			Panel, Control (Mounts Nameplate) WCVD-25,
"	9989-475-001			Panel, Control (Mounts Nameplate) WCVD-40
"	9989-476-001			Panel Control Assembly(panel only)
*	9545-008-026			Screw, Vault Mtg
"	9467-024-001			Post Locator Top
"	8640-411-003			Nut, Switch Locking
"	9355-001-001			Locator Panel
"	9545-008-023			Screw, Guide

7	9538-178-001		Spacer Pushbutton (Micro)
8	9486-150-001		Retainer Pushbutton (Micro)
9	8640-424-002		Nut
10	9035-060-001		Pushbutton Control (coin)
2	9185-008-001	Not Available	Filler Pushbutton Control
11	9473-004-001	9473-004-004	V Coin Control
12	9538-157-018		Spacer Plastic #6x9/16
13	8640-411-003		Nut, Switch Locking
14	9627-797-001		Wiring Harness LED PCB
15	9627-791-003		Wiring Harness doorlock safety switch
"	9627-791-004		Wiring Harness, Door Lock
16	9473-004-001	9473-004-004	V Coin Control
17	9538-157-018		Spacer Plastic #6x9/16
18	8640-411-003		Nut, Switch Locking
19	9794-001-001		Wiring Harness
20	9538-157-018		Spacer Plastic #6x9/16
21	8640-411-003		Nut, Switch Locking
*	9732-122-001	9807-099-001	Box Assembly Coin Vault ESD W/lock & Key Chrome
22	9412-114-001		Nameplate Decal, Control Panel (one piece) WCVD-40
"	9412-113-001		Nameplate Decal, Control Panel (one piece) WCVD-25
"	9412-112-001		Nameplate Decal, Control Panel (one piece) WCVD-18
"	9412-115-001		Nameplate Decal, Control Panel (one piece) WCVD-55
"	9412-130-001		Nameplate Decal, Control Panel (one piece) WCVD-75
*	9922-011-001	9922-011-001P	Solenoid Assy.
"	8640-412-005		NUT-HEXKEPS,#8-32
23	8612-001-001		Battery (used on Control PCB)
24	9021-001-001		Acceptor, Coin -,25 (See Coin Handling Group)

the laundry company[®]