


Maytag A15CM 01 - FRONT VIEW



230-50 INFORMATION IS ON LAST PAGE

Maytag [Commercial Maytag A15CM Washer Parts](#) Parts Diagram 01 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TEMPERATURE SWITCH
002	NLA		Not Available	OUTER CASE (WHT)
003	203188		Not Available	TIMER ACCESS DOOR (WHT)
004	NLA		Not Available	CONTROL COVER
005	NLA		Not Available	OUTER CASE (WHT)
006	NLA		Not Available	TOP COVER (WHT)
007	NLA		Not Available	OUTER CASE (WHT)
008	NLA		Not Available	3 BULB SIGNAL LIGHT (120-60)
009	NLA		Not Available	CABINET (WHT)
010	NLA		Not Available	CONTROL PANEL W/LENS
011	203761			DOOR, ACCESS (WHT)
012	NLA		Not Available	CONTROL CENTER (WHT)
013	NLA		Not Available	COIN BOX (WHT)
014	NLA		Not Available	SUPER SECURITY COIN BOX

015	204010		Temperature Switch
016	NLA	Not Available	CONTROL PANEL ASSEMBLY
017	204051	22204051	Knob
018	NLA	Not Available	CONTROL COVER (WHT)
019	204109		Light, Signal
020	NLA	Not Available	CONTROL CENTER W/GASKET
021	NLA	Not Available	CONTROL CENTER W/GASKET
022	NLA	Not Available	CONTROL CENTER W/GASKET
023	204439		Screw And Fstner Assembly
024	204445		Screw And Fastener Assembly
025	204968		Plunger And Bracket Assembly--W
026	205415	279347	Switch-Lid
027	210198		Fastener
028	210385		Lock Nut For Adjustable Leg
029	210684		Foot, Adjustable Leg
030	NLA	Not Available	SCREW, No.8 X 1/2 INCH
031	211726		Hinge, Ball Lid
032	212073	216073	LID (WHITE)
033	212519	488234	Screw 8-32 X 1/4
034	NLA	Not Available	KNURLED NUT, TEMP. SWITCH
035	212716		Bumper, Lid
036	212982	22001650	Fastener, Spring
037	212998	Not Available	PANEL, FRONT (WHT)
038	213007		Xfor Cabinet See Cabinet, Back
039	NLA	Not Available	GASKET UNDER CONTROL CENTER
040	213099		Lens For Control Panel
041	213122	27001200	Screw
042	NLA	Not Available	LID BUMPER
043	214650		Screw For 2-4051 Knob
044	Y302699	22003428	Leg, Adjustable
045	NLA	Not Available	EXTERNAL/INTERNAL LOCK WASHER

