



Maytag A15CT 02 - CT CONTROL CENTER



** CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR FOR KEYS, LOCKS, TICKETS, TICKET DISPENSERS AND CONTROL CENTERS.

[Maytag Commercial Maytag A15CT Washer Parts Parts Diagram 02 - CT CONTROL CENTER](#)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	TIMER MOTOR, A
003	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
004	202477	22003292		Control As
005	203188		Not Available	TIMER ACCESS DOOR (WHT)
006	NLA		Not Available	OUTER CASE (WHT)
007	NLA		Not Available	HARNES, TICKET CONTROL
008	NLA		Not Available	MTG. STRAP---NA
009	NLA		Not Available	ACCESS DOOR (WHT)
010	NLA		Not Available	TICKET RECEIVER ASSEMBLY
011	NLA		Not Available	TIMER
012	NLA		Not Available	ACCESS DOOR (WHT)
013	NLA		Not Available	TIMER W/KNOB & PIN
014	NLA		Not Available	TIMER W/KNOB & PIN (CT)

015	NLA		Not Available	CONTROL CENTER W/GASKET
016	204973			Motor, Timer
017	NLA		Not Available	DOUBLE MELT CLIP W/DEFLECTOR
018	210294	910309		Washer, Mounting Strap
019	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
020	212276	W10116760		Screw
021	NLA		Not Available	GASKET UNDER CONTROL CENTER
022	NLA		Not Available	FRONT PLATE, TICKET CONTROL
023	213089			Knob For Timer
024	NLA		Not Available	LATCH, ACCESS DOOR
025	NLA		Not Available	MOISTURE SHIELD
026	Y312300			Groov-Pin
027	910647	489355		Screw, 8 X 1/2

