


# Maytag A15CT 09 - POWER UNIT & CENTER ASSEMBLY



Maytag Commercial Maytag A15CT Washer Parts Parts Diagram 09 - POWER UNIT & CENTER ASSEMBLY  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SEAL, AGITATOR DRIVE SHAFT
002	Y014792	<a href="#">6-0A57420</a>		Seal- Agitator
003	<a href="#">Y014827</a>			Washer-Center Shaft
004	<a href="#">Y014839</a>			Collar-Drive Shaft
005	<a href="#">Y015149</a>			Brass Washer-Agitator Seal
006	<a href="#">Y015494</a>			Stop Ring-Agitator Shaft
007	<a href="#">Y015629</a>			Bolt, Grinding Chamber
008	NLA		Not Available	DOWEL PIN
009	<a href="#">Y015666</a>			Washer, Retaining -
010	<a href="#">Y015667</a>			Retaining Ring
011	<a href="#">Y015902</a>			Spring For Agitator
012	038313	<a href="#">22038313</a>		Wrench, Spanner
013	<a href="#">Y038555</a>			Tool-Install Center Shaft
014	NLA		Not Available	CAP SCREW (3/8-16 X 1)
015	<a href="#">Y053241</a>			Set Screw, Motor Pulley
016	Y054866	<a href="#">486009</a>		Lockwasher

017	<a href="#">Y054867</a>		Washer, Lock
018	<a href="#">Y055977</a>		TURBINE OIL, 4 OZ.
019	<a href="#">Y055978</a>		Rubber Adhesive, 2 Oz Tube
020	<a href="#">Y056016</a>		Center Seal Grease
021	Y056080	<a href="#">6-0560800</a>	Oil
022	200730	<a href="#">22002124</a>	Shaft- Agi
023	NLA	Not Available	GEAR CASE COVER ASSEMBLY
024	200824	<a href="#">6-2040130</a>	Tub Bearin
025	NLA	Not Available	PITMAN W/WRIST PIN
026	201537	<a href="#">6-2095720</a>	Mounting S
027	202521	<a href="#">6-2095720</a>	Mounting S
028	NLA	Not Available	GEAR HOUSING W/STUDS & TUBE
029	NLA	Not Available	PART NOT USED
030	203383	<a href="#">W10172458</a>	Transmison
031	NLA	Not Available	GEAR KIT, BAKELITE AGITATOR
032	<a href="#">204967</a>		Gear Kit-Power Fin Agitator
033	NLA	Not Available	COUNTERWEIGHT
034	<a href="#">210054</a>		Pinion
035	NLA	Not Available	LOCK WASHER
036	NLA	Not Available	RETAINING RING
037	<a href="#">210183</a>		Groove Pin
038	<a href="#">210286</a>		Seal
039	<a href="#">210315</a>		Pinion
040	NLA	Not Available	BOLT
041	210632	<a href="#">22210632</a>	Gasket
042	NLA	Not Available	SEGMENT
043	NLA	Not Available	BEARING
044	211028	<a href="#">22001586</a>	Deflector, Water
045	211047	<a href="#">6-2110472</a>	Nut- Clamp
046	<a href="#">211089</a>		Lug, Stop Pulley
047	211090	<a href="#">22003555</a>	Washer, Stop Lug
048	<a href="#">211100</a>		Washer, Outer Tub
049	<a href="#">211130</a>		Bearing Liner, Tub Bearing
050	<a href="#">211210</a>		Washer, Clamping Nut
051	211375	<a href="#">681582</a>	Screw
052	211483	<a href="#">6-2114830</a>	Washer- SP
053	<a href="#">211484</a>		Washer, Lug
054	<a href="#">211486</a>		Screw, 3/8-16 X 1/2 Inch
055	NLA	Not Available	GROOV-PIN
056	211618	<a href="#">22001423</a>	Set Screw, Mounting Stem
057	NLA	Not Available	SPRING, TUB SEAL
058	<a href="#">212988</a>		Part Not Used
059	NLA	Not Available	WASHER, GEARS