



Maytag [Commercial Maytag A18CT Washer Parts](#) Parts Diagram 03 - CT CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	TIMER MOTOR, A
003	202477	22003292		Control As
004	NLA		Not Available	OUTER CASE-WHITE
005	NLA		Not Available	HARNES FOR TICKET CONTROL
006	NLA		Not Available	MTG. STRAP---NA
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	NLA		Not Available	ACCESS DOOR (WHITE)
009	NLA		Not Available	TIMER WITH KNOB AND PIN
010	NLA		Not Available	CONTROL CENTER-WHITE
011	NLA		Not Available	WIRE HARNES
012	NLA		Not Available	MAIN WIRE HARNES
013	NLA		Not Available	HARNES FOR TICKET CONTROL
014	204973			Motor, Timer
015	NLA		Not Available	DOUBLE MELT CLIP

015	NLA	Not Available	W/DEFLECTO
016	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
017	212276	W10116760	Screw
018	NLA	Not Available	GASKET UNDER CONTROL CENTER
019	NLA	Not Available	FRONT PLATE F/TICKET CONTROL
020	NLA	Not Available	LATCH FOR ACCESS DOOR
021	NLA	Not Available	MOISTURE SHIELD
022	910309		Washer, Mounting Strap
023	910647	489355	Screw, 8 X 1/2

