


# Maytag A23CA 03 - TUB, AGITATOR, MOUNTING STEM & SEAL



Maytag Commercial Maytag A23CA Washer Parts Parts Diagram 03 - TUB, AGITATOR, MOUNTING STEM & SEAL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y0A4298	<a href="#">6-0A57420</a>		Seal- Agitator
002	<a href="#">Y015494</a>			Stop Ring-Agitator Shaft
003	<a href="#">Y015666</a>			Washer, Retaining -
004	<a href="#">Y015667</a>			Retaining Ring
005	<a href="#">Y054867</a>			Washer, Lock
006	<a href="#">200744</a>	<a href="#">W10175939</a>		Bolt
007	200824	<a href="#">6-2040130</a>		Tub Bearin
008	<a href="#">200846</a>			Clamp - Tub Cover
009	200900	<a href="#">616099</a>		Clamp
010	201379		Not Available	AGITATOR - BLACK
011	NLA		Not Available	INNER TUB
012	201537	<a href="#">6-2095720</a>		Mounting S
013	<a href="#">201575</a>			Clamp, Hose
014	201765		Not Available	COVER, TUB
015	202515	<a href="#">596669</a>		Clamp, Manifold
016	202521	<a href="#">6-2095720</a>		Mounting S

017	203228		Not Available	TUB, INNER PART NOT USED
018	204012	<a href="#">6-2095720</a>		Mounting S
019	204013	<a href="#">6-2040130</a>		Tub Bearin
020	<a href="#">204060</a>			Agitator W/Cap, Screw And Washer
021	<a href="#">205254</a>	<a href="#">W10175938</a>		Bolt
022	<a href="#">205484</a>			Tub, Outer Part Not Used
023	205486		Not Available	PART NOT USED
024	<a href="#">205529</a>			Nut And Bolt Kit For Tub Clam
025	205614	<a href="#">205613</a>		Water Valve
026	<a href="#">206154</a>			Injector Tube With Seal
027	206380		Not Available	COVER, TUB
028	206478		Not Available	SCREW & WASHER FOR AGITATOR
029	206531	<a href="#">W10276607</a>		Hose
030	206683	<a href="#">206680</a>		Water Injector Assembly
031	211047	<a href="#">6-2110472</a>		Nut- Clamp
032	<a href="#">211100</a>			Washer, Outer Tub
033	<a href="#">211130</a>			Bearing Liner, Tub Bearing
034	<a href="#">211210</a>			Washer, Clamping Nut
035	<a href="#">211223</a>			Bumper, Unbalance
036	<a href="#">211232</a>			Seal, Tub Cover
037	211618	<a href="#">22001423</a>		Set Screw, Mounting Stem
038	<a href="#">211641</a>			Clamp, 1-1/16"
039	212942	<a href="#">22001619</a>		Tube, Water Level Switch
040	<a href="#">Y212989</a>			Hose, Outer Tub To Pump
041	<a href="#">213013</a>			Hose, Injector
042	<a href="#">213015</a>			Nozzle, Injector
043	213016	<a href="#">216201</a>		Nozzle
044	<a href="#">213045</a>			Hose, Outer Tub Part Not Used
045	213057	<a href="#">22213057</a>		Sleeve- In
046	<a href="#">214705</a>			Cap, Capacitor
047	<a href="#">214725</a>			Cap For Spout-Outer Tub
048	214739	<a href="#">596669</a>		Clamp, Manifold
049	<a href="#">215120</a>			Seal For Injector Tube
050	<a href="#">215232</a>			Bumper, Unbalance
051	<a href="#">215233</a>			Seal For Injector Tube
052	<a href="#">Y215234</a>			Hose, Injector Fill
053	<a href="#">215235</a>			Tube, Injector
054	<a href="#">215447</a>			Sleeve For Injector
055	Y310632	<a href="#">1163839</a>		Screw