


# Maytag A23CDL 01 - CD CONTROL PANEL, TOP COVER & LID SWITCH



Maytag Commercial Maytag A23CDL Washer Parts Parts Diagram 01 - CD CONTROL PANEL, TOP COVER & LID SWITCH

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	BIT, TORX (2-15506 SCREW)
002	<a href="#">Y201808</a>			Converter
003	NLA		Not Available	STRAP, MOUNTING
004	<a href="#">203970</a>			Switch, Water Level
005	<a href="#">204445</a>			Screw And Fastener Assembly
006	NLA		Not Available	CORD, POWER
007	<a href="#">204968</a>			Plunger And Bracket Assembly--W
008	205415	<a href="#">279347</a>		Switch-Lid
009	205651		Not Available	TOP COVER-WHITE
010	NLA		Not Available	(ALM)
011	<a href="#">206881</a>			Indicator, Light
012	NLA		Not Available	HARNESS, WIRE
013	206808	<a href="#">W10135389</a>		Push Button And Switch Assembly
014	206824	<a href="#">W10133335</a>		Relay, Motor

015	206825	<a href="#">215516</a>		Plate, Back-Up
016	NLA		Not Available	BACK BRACKET ASSEMBLY
017	<a href="#">206828</a>			Battery
018	<a href="#">207766</a>			Transformer
019	<a href="#">211294</a>	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
020	<a href="#">211500</a>			Washer, Bracket To Top Cover
021	<a href="#">211726</a>			Hinge, Ball Lid
022	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
023	212276	<a href="#">W10116760</a>		Screw
024	<a href="#">212716</a>			Bumper, Lid
025	212942	<a href="#">22001619</a>		Tube, Water Level Switch
026	212949	<a href="#">22001866</a>		Screw, Relay
027	<a href="#">213718</a>			Plunger, Lid Switch
028	<a href="#">213720</a>			Spring, Lid Switch
029	<a href="#">214610</a>			Bumper, Lid
030	<a href="#">214805</a>			Pin For Unbalance Lever
031	214813		Not Available	LEVER FOR LID SWITCH
032	214884	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
033	<a href="#">214898</a>			Cover For Lid Switch
034	214901		Not Available	LID-WHITE
035	NLA		Not Available	(ALM)
036	<a href="#">214987</a>			Moisture Barrier For Switch
037	<a href="#">215003</a>			Fastener, Panel And Bracket
038	215236	<a href="#">214804</a>		Unbalance Lever
039	<a href="#">215273</a>			Clip, Spring Relay
040	<a href="#">215506</a>			Screw, Control Panel Overlay
041	215510		Not Available	SUPPORT, PC BOARD
042	<a href="#">Y215513</a>			Standoff, Circuit Board
043	215515		Not Available	COVER, DISPLAY
044	215517	<a href="#">W10131113</a>		Push Button
045	<a href="#">215519</a>			Panel, Control
046	<a href="#">215526</a>			Screw, Circuit Board
047	215527	<a href="#">W10140652</a>		Screw, 6-20 X 1/2
048	<a href="#">Y313559</a>			Screw
049	Y314322	<a href="#">211251</a>		Screw, Transformer
050	410296	<a href="#">596669</a>		Clamp, Manifold
051	<a href="#">410635</a>			Fastener
052	910182	<a href="#">25-7809</a>		Screw, No.6-20 1/2 Flthd Torx
053	<a href="#">910309</a>			Washer, Mounting Strap
054	<a href="#">911267</a>			Screw, Pump Cover
055	<a href="#">912077</a>			Locknut, Reader Harness