


MODEL A23CD

CONTROL PANEL & CONTROL CENTER COMPONENTS



Maytag [Commercial Maytag A23CDL Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	203188		Not Available	TIMER ACCESS DOOR (WHT)
003	203188L		Not Available	ACCESS DOOR-ALMOND
004	NLA		Not Available	MTG. STRAP---NA
005	205423	208883		Coin Box K
006	205423L	208883		Coin Box K
007	206780			Control Cover Assembly
008	206780L	206780		Control Cover Assembly
009	206794		Not Available	SWITCH (W/NUT)
010	206795		Not Available	COIN DROP METER ASSY
011	206795L		Not Available	COIN DROP METER ASSY
012	206799			Optic Switch Assembly
013	NLA		Not Available	COIN REJECTOR (CANADA)
014	NLA		Not Available	COIN BOX (WHT)
015	NLA		Not Available	(ALM)
016	NLA		Not Available	COIN REJECTOR

017	207672	208884	Coin Box K
018	207672L	208884	Coin Box K
019	207673	22001407	Case, Coin Slide
020	207673L	22001408	(ALM)
021	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
022	212276	W10116760	Screw
023	212328	W10139762	Hex Nut, 3/4-27
024	213035		Bolt, Locking
025	213750	W10133266	Cam-Lock
026	214660		Gasket, Control Center
027	910181		Lockwasher, Terminal Block
028	910309		Washer, Mounting Strap

the laundry company[®]

lows
the laundry company[®]

lows
the laundry company[®]