


# Maytag A23CSL 05 - TUB, AGITATOR, MOUNTING STEM & SEAL



Maytag [Commercial Maytag A23CSL Washer Parts](#) Parts Diagram 05 - TUB, AGITATOR, MOUNTING STEM & SEAL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y0A4298	<a href="#">6-0A57420</a>		Seal- Agitator
002	<a href="#">Y015494</a>			Stop Ring-Agitator Shaft
003	<a href="#">Y015666</a>			Washer, Retaining -
004	<a href="#">Y054867</a>			Washer, Lock
005	<a href="#">200744</a>	<a href="#">W10175939</a>		Bolt
006	200824	<a href="#">6-2040130</a>		Tub Bearin
007	<a href="#">200846</a>			Clamp - Tub Cover
008	200900	<a href="#">616099</a>		Clamp
009	201379		Not Available	AGITATOR - BLACK
010	NLA		Not Available	INNER TUB
011	NLA		Not Available	INNER TUB
012	201537	<a href="#">6-2095720</a>		Mounting S
013	<a href="#">201575</a>			Clamp, Hose
014	201765		Not Available	COVER, TUB
015	202515	<a href="#">596669</a>		Clamp, Manifold
016	202521	<a href="#">6-2095720</a>		Mounting S

018	204012	<a href="#">6-2095720</a>	Mounting S
019	204013	<a href="#">6-2040130</a>	Tub Bearin
021	<a href="#">205254</a>	<a href="#">W10175938</a>	Bolt
023	205486		Not Available PART NOT USED
024	<a href="#">205529</a>		Nut And Bolt Kit For Tub Clam
025	205614	<a href="#">205613</a>	Water Valve
026	<a href="#">206154</a>		Injector Tube With Seal
027	206380		Not Available COVER, TUB
028	206531	<a href="#">W10276607</a>	Hose
029	206683	<a href="#">206680</a>	Water Injector Assembly
030	211047	<a href="#">6-2110472</a>	Nut- Clamp
031	<a href="#">211100</a>		Washer, Outer Tub
032	<a href="#">211130</a>		Bearing Liner, Tub Bearing
033	<a href="#">211210</a>		Washer, Clamping Nut
034	<a href="#">211223</a>		Bumper, Unbalance
035	<a href="#">211232</a>		Seal, Tub Cover
036	211618	<a href="#">22001423</a>	Set Screw, Mounting Stem
037	<a href="#">211641</a>		Clamp, 1-1/16"
038	212942	<a href="#">22001619</a>	Tube, Water Level Switch
039	<a href="#">Y212989</a>		Hose, Outer Tub To Pump
040	<a href="#">213013</a>		Hose, Injector
041	<a href="#">213015</a>		Nozzle, Injector
042	213016	<a href="#">216201</a>	Nozzle
044	213057	<a href="#">22213057</a>	Sleeve- In
045	<a href="#">214705</a>		Cap, Capacitor
046	<a href="#">214725</a>		Cap For Spout-Outer Tub
047	214739	<a href="#">596669</a>	Clamp, Manifold
048	<a href="#">215120</a>		Seal For Injector Tube
049	<a href="#">215232</a>		Bumper, Unbalance
050	<a href="#">215233</a>		Seal For Injector Tube
051	<a href="#">Y215234</a>		Hose, Injector Fill
052	<a href="#">215235</a>		Tube, Injector
053	<a href="#">215447</a>		Sleeve For Injector
054	Y310632	<a href="#">1163839</a>	Screw

