


Maytag CGT8000XQ0 02 - DRYER CABINET PARTS



Maytag [Commercial Maytag CGT8000XQ0 Stacked Washer and Dryer Parts](#) Parts Diagram 02 - DRYER CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8317340			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	8565048			Panel, Side
5	8564010			Assembly, Switch And Actuator
6	8519459			Clip, Toe Panel
7	8565054			Panel, Side
8	8563730	W10336080		Top
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	697750	W10470674		Dryer Exhaust Kit
13	W10344192			Idler Assembly
14	3978776			Bracket, Gas Pipe Switch

15	8564011		Bracket-Switch
16	W10167613		Wire, Belt Switch
17	343641	681414	Screw, 10AB X 1/2
19	W10128087	W10318609	Switch, Assembly Door
20	8066115	3394331	Plate Cover
21	8565083		Ramp, Door
22	8565122		Strike, Door
23	8539892		Wire-Motor To Belt Switch
24	W10198309		Base And Bracket, Vault Assembly
25	8565059		Panel, Rear
26	W10139766	W10396034	Motor Assembly 60 Hz
27	3394341	W10299847	Pulley-Motor
28	W10131172		Belt, Drive
29	W10198376		Bracket, Burner
30	W10135695		Bracket, Motor
31	3401401	3401402	Cord, Power
32	49026		4" - 90° Elbow
33	693995		Screw, Hex Head
34	8563747		Exhaust Pipe Medium Pipe
35	8563750		Exhaust Pipe
36	8563749		Exhaust Pipe
37	W10133261		Vault Switch, Bracket
38	W10002600		Screw, 6-20 X 1 1/4
39	3390647	488729	Screw
40	3387242		Seal, Front Panel
41	3393008	308685	Side Trim)
42	W10376685		Control Board
43	8563727		Bracket, Control
44	8565043		Plug, Strip Front Panel
45	3357011	308685	Side Trim)
46	W10117421		Front Panel
47	W10155571		Switch, Assembly
48	8318396		Foam-Seal
49	W10198363		Enclosure-CCU Asm.
50	W10212660		Pad, Sound Dampening
51	W10266747		Channel-Water, Dryer
52	3393657		Restrainer, Belt
53	3405160		Belt, Drive
54	W10198373		Retainer-Base
NI	279818	W10470674	Dryer Exhaust Kit