


Maytag DE18CM 06 - CM CONTROL CENTER



Maytag Commercial Maytag DE18CM Dryer Parts Parts Diagram 06 - CM CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	203188		Not Available	TIMER ACCESS DOOR (WHT)
003	203188L		Not Available	ACCESS DOOR-ALMOND
004	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
005	NLA		Not Available	MTG. STRAP---NA
006	NLA		Not Available	COIN DROP ASSEMBLY
007	NLA		Not Available	COIN BOX-WHITE---NA
008	NLA		Not Available	COIN BOX-ALMOND
009	NLA		Not Available	COIN BOX - HARVEST WHEAT
010	205416			Guard For Coin Box
011	205423	208883		Coin Box K
012	205423L	208883		Coin Box K
013	205423M	208883		Coin Box K
014	210720			Rivet, Bearing To Tumbler Frnt

015	211168	W10139210		Screw, 8-18 X 5/16
016	NLA		Not Available	FASTENER
017	211251			Screw, Transformer
018	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
019	211790			Lock Ring For Timer Shaft
020	212328	W10139762		Hex Nut, 3/4-27
021	NLA		Not Available	GASKET UNDER CONTROL CENTER
022	213035			Bolt, Locking
023	Y301774			Switch For Coin Slide
024	NLA		Not Available	OUTER CASE-WHITE
025	NLA		Not Available	OUTER CASE-ALMOND
026	NLA		Not Available	OUTER CASE-HARVEST WHEAT
027	Y303707			Wire Assembly
028	Y303743			Timer
029	Y303445		Not Available	MAIN WIRE HARNESS
030	NLA		Not Available	MAIN WIRE HARNESS
031	NLA		Not Available	CONTROL CENTER-WHITE
032	NLA		Not Available	CONTROL CENTER-HARVEST WHEA
033	NLA		Not Available	TIMER MOTOR
034	NLA		Not Available	COIN BOX COVER
035	Y312068			Return Lever
036	Y312069			Stop For Actuator
037	NLA		Not Available	RATCHET FOR TIMER
038	Y312071			Return Spring For Actuator
039	312073			Spring Washer
040	312250			Timer Support Bracket
041	NLA		Not Available	WASHER
042	Y313309			Timer Actuator Lever
043	Y313439		Not Available	INSTRUCTION LABEL
044	314073			Time Indicator Gage
045	410730			Washer
046	910181			Lockwasher, Terminal Block
047	910309			Washer, Mounting Strap

