


Maytag DE23CD 02 - REAR VIEW



Maytag Commercial Maytag DE23CD Dryer Parts Parts Diagram 02 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	210385			Lock Nut For Adjustable Leg
003	210684			Foot, Adjustable Leg
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	213007			Xfor Cabinet See Cabinet, Back
006	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
007	301548			Clamp, Ground Wire
008	Y302699	22003428		Leg, Adjustable
009	NLA		Not Available	SCREW & WASHER ASSY.
010	Y305087	22003544		Adjustable Leg W/Foot And Nut
011	Y305190	307104		Top Cover Assembly
012	NLA		Not Available	(ALM)
013	NLA		Not Available	(H. WHEAT)

014	NLA		Not Available	CABINET (WHT)
015	NLA		Not Available	(ALM)
016	NLA		Not Available	(H. WHEAT)
017	NLA		Not Available	COUPLING COLLAR (WHT)
018	NLA		Not Available	(ALM)
019	NLA		Not Available	(H. WHEAT)
020	Y310632	1163839		Screw
021	310933	33002194		Nut, Speed
022	311155			Ground Wire And Clamp
023	Y311423	489483		Screw 10-32 X 1/2
024	311484	112432		Nut
025	Y312184			Strap, Grounding
026	Y312209	W10001200		Screw
027	Y312904			Bracket, Terminal Block
028	Y312905		Not Available	COVER, TERMINAL
029	Y312951		Not Available	ACCESS COVER, BACK
030	313122			Screw - Baffle To Tumbler
031	Y313559			Screw
032	Y313561			Screw---NA
033	NLA		Not Available	TOP COVER PLATE
034	314663	214354		Screw, Top Cover To Cabnt.
035	400008			Block, Terminal

