


Maytag DE26CT 03 - CONTROL PANEL-CT MODELS

SECTION: CT CONTROL PANEL
 MODEL: DE-DG26CT



Issue Date: 11/90

16

Maytag [Commercial Maytag DE26CT Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL-CT MODELS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	212950	M0227520		Screw-Tc No.6-32 X 13/16", Preform SwiTch
002	NLA		Not Available	SPRING LEVER, RELAY
003	212949	22001866		Screw, Relay
004	NLA		Not Available	SPACER, ADVANCE RELAY
005	212951			Screw, No.6-32 X 1/4 Inch
"	305393			Solenoid For Relay Assembly
006	307237	W10327105		Switch, Cycle Selection
007	NLA		Not Available	PILOT LIGHT
008	NLA		Not Available	CONTROL COVER (WHT)
009	212276	W10116760		Screw
010	306941	W10149462		Switch, Push-To-Start
011	Y313588	488234		Screw 8-32 X 1/4
012	314912		Not Available	BRACKET, CONTROL PANEL (WHT)
"	NLA		Not Available	(ALM)
013	312751			Lockwasher, Start Switch

014	Y312706	422617	Nut
015	212277		Screw, No.8 X 1/2 Inch
016	Y312702		Knurled Nut, Start Switch
017	215564		Lens, Indicator Light
018	306938		Knob, Selector Switch
019	NLA	Not Available	CONTROL PANEL COMMERCIAL DRYER
020	NLA	Not Available	WIRE HARNESS---NA
021	205810		Wire, Ground
"	211252		Screw, Ground Wire
022	307105	Not Available	COVER, TOP ASSY. (WHT)
"	NLA	Not Available	(ALM)
023	215003		Fastener, Panel And Bracket
024	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
025	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	NLA	Not Available	RELAY BRACKET
026	Y303787	Not Available	SWITCH FOR RELAY

