

011	NLA		Not Available	COVER PLATE
"	Y313559			Screw
012	NLA		Not Available	SCREW & WASHER ASSY.
013	213007			Xfor Cabinet See Cabinet, Back
"	NLA		Not Available	CABINET (WHT)
"	Y310632	1163839		Screw
014	310933	33002194		Nut, Speed
015	NLA		Not Available	SUPPORT ASSY
"	Y310632	1163839		Screw
016	213007			Xfor Cabinet See Cabinet, Back
"	Y313561			Screw---NA
"	NLA		Not Available	CABINET, LOWER (WHITE)
"	Y310632	1163839		Screw
017	210385			Lock Nut For Adjustable Leg
018	Y302699	22003428		Leg, Adjustable
019	210684			Foot, Adjustable Leg
020	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313561			Screw---NA
"	Y312951		Not Available	ACCESS COVER, BACK
021	301548			Clamp, Ground Wire
"	313122			Screw - Baffle To Tumbler
022	311155			Ground Wire And Clamp

the laundry company[®]

the laundry company[®]