



# Maytag DE27CT 08 - FRONT PANEL & DOOR ASSEMBLY

SECTION: FRONT PANEL & DOOR ASSEMBLY  
 MODEL: DE-DG27CS-CT



Issue Date: 10/90

Maytag [Commercial Maytag DE27CT Dryer Parts](#) Parts Diagram 08 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">314937</a>			Seal, Front Panel
002	NLA		Not Available	PART NOT USED
003	<a href="#">Y313907</a>			Fastener, Twin
004	<a href="#">204439</a>			Screw And Fstner Assembly
"	NLA		Not Available	PANEL, FRONT (WHT)
005	212982	<a href="#">22001650</a>		Fastener, Spring
006	<a href="#">Y310376</a>			Clip, Door Switch Harness
007	<a href="#">Y305753</a>	<a href="#">W10169313</a>		Switch-Dor
008	314935	<a href="#">33001192</a>		Seal, Door
009	308069		Not Available	DOOR, INNER W/GASKET
010	307099	<a href="#">33001230</a>		Hinge, Door
"	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
011	NLA		Not Available	DOOR, COMPLETE LESS HINGES (WH
012	314967		Not Available	DOOR W/WINDOW OUTER HALF (WHT)
"	NLA		Not Available	DOOR W/WIN CUT OUT

	NLA		OUTER ALMNA
013	<a href="#">314939</a>		Handle, Door
"	<a href="#">314974</a>		Handle, Door
"	<a href="#">314975</a>		Handle, Door
014	314936	<a href="#">33001305</a>	Strike, Door
"	314944	<a href="#">33001305</a>	Strike, Door
015	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
016	<a href="#">306436</a>		Door Latch Kit--W
017	NLA	Not Available	PART NOT USED
018	<a href="#">Y314025</a>		Latch For Access Door
019	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
020	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION
021	314941	Not Available	LABEL, INSTRUCTION
022	NLA	Not Available	INSTRUCTION LABEL

