


# Maytag DG18CM 09 - FRONT PANEL-REAR VIEW



Maytag Commercial Maytag DG18CM Dryer Parts Parts Diagram 09 - FRONT PANEL-REAR VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.4-40 X 1/4
002	<a href="#">Y055978</a>			Rubber Adhesive, 2 Oz Tube
003	<a href="#">204439</a>			Screw And Fstner Assembly
004	212949	<a href="#">22001866</a>		Screw, Relay
005	212982	<a href="#">22001650</a>		Fastener, Spring
006	NLA		Not Available	HINGE ASSEMBLY----N
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	NLA		Not Available	ACCESS DOOR-ALMOND
009	NLA		Not Available	DOOR COMPLETE-WHITE
010	NLA		Not Available	DOOR COMPLETE-HARVEST WHEAT
011	Y303441		Not Available	DOOR SWITCH
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	<a href="#">Y304298</a>			Hinge - Lower
015	NLA		Not Available	HINGE - UPPER

016	NLA	Not Available	HINGE - LOWER
017	NLA	Not Available	HINGE - UPPER
018	310560	<a href="#">74004005</a>	Screw, 6-32 X 5/16"
019	NLA	Not Available	STRIKE PLATE
020	NLA	Not Available	BUSHING FOR ACCESS STUD
021	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
022	NLA	Not Available	DOOR PANEL-WHITE
023	NLA	Not Available	DOOR PANEL-WHITE
024	NLA	Not Available	DOOR PANEL-HAVEST WHEAT
025	Y312891	Not Available	DOOR LINER - INNER HALF
026	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION
027	<a href="#">Y313927</a>		INSTRUCTION LABEL
028	<a href="#">314077</a>		Door Seal
029	NLA	Not Available	GAS IGNITION LABEL
030	<a href="#">314286</a>		Seal For Front Panel

