


Maytag DG18CT 09 - FRONT PANEL-REAR VIEW



Maytag Commercial Maytag DG18CT Dryer Parts Parts Diagram 09 - FRONT PANEL-REAR VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.4-40 X 1/4
002	Y055978			Rubber Adhesive, 2 Oz Tube
003	204439			Screw And Fstner Assembly
004	212949	22001866		Screw, Relay
005	212982	22001650		Fastener, Spring
006	NLA		Not Available	HINGE ASSEMBLY----N
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	NLA		Not Available	ACCESS DOOR-ALMOND
009	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
010	Y303370			Door Switch
011	NLA		Not Available	DOOR COMPLETE-WHITE
012	NLA		Not Available	DOOR COMPLETE-HARVEST WHEAT
013	NLA		Not Available	FRONT PANEL-WHITE
014	NLA		Not Available	FRONT PANEL-HARVEST WHEAT

015	NLA	Not Available	FRONT PANEL-HARVEST WHEAT
016	Y304298		Hinge - Lower
017	NLA	Not Available	HINGE - UPPER
018	NLA	Not Available	HINGE - LOWER
019	NLA	Not Available	HINGE - UPPER
020	310560	74004005	Screw, 6-32 X 5/16"
021	NLA	Not Available	STRIKE PLATE
022	NLA	Not Available	BUSHING FOR ACCESS STUD
023	312369		Sleeve, Access Panel Stud Part Not Used
024	NLA	Not Available	DOOR PANEL-WHITE
025	NLA	Not Available	DOOR PANEL-HAVEST WHEAT
026	Y312891	Not Available	DOOR LINER - INNER HALF
027	Y313340		LABEL, LINT SCREEN INSTRUCTION
028	Y313927		INSTRUCTION LABEL
029	314077		Door Seal
030	NLA	Not Available	GAS IGNITION LABEL
031	314286		Seal For Front Panel

