


Maytag DG18CT 10 - FRONT PANEL & DOOR ASSY (SERIES 04)



Maytag Commercial Maytag DG18CT Dryer Parts Parts Diagram 10 - FRONT PANEL & DOOR ASSY (SERIES 04)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204439			Screw And Fstner Assembly
002	212949	22001866		Screw, Relay
003	212982	22001650		Fastener, Spring
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	NLA		Not Available	ACCESS DOOR-ALMOND
006	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
007	Y304576	W10169313		Switch-Dor
008	Y304577	33001230		Hinge, Door
009	Y304579	Y306668		DOOR (WHT)
010	NLA		Not Available	DOOR-ALMOND
011	NLA		Not Available	DOOR-HARVEST WHEAT
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	NLA		Not Available	INNER DOOR WITH KNOB & SCRE

015	NLA	Not Available	KNOB AND SCREW
016	306436		Door Latch Kit--W
017	Y310376		Clip, Door Switch Harness
018	NLA	Not Available	BUSHING FOR ACCESS STUD
019	NLA	Not Available	SCREW---NA
020	312369		Sleeve, Access Panel Stud Part Not Used
021	Y313340		LABEL, LINT SCREEN INSTRUCTION
022	Y313907		Fastener, Twin
023	Y313908		DOOR PANEL-WHITE
024	NLA	Not Available	DOOR PANEL-ALMOND
025	NLA	Not Available	DOOR PANEL-HARVEST WHEAT
026	Y313910		Clip, Door Liner To Outer Panel
027	Y313911		Door Strike Retainer
028	Y313927		INSTRUCTION LABEL
029	Y314025		Latch For Access Door
030	Y314062		Screw, Door Hinge And Panel
031	314077		Door Seal
032	NLA	Not Available	GAS IGNITION LABEL
033	314286		Seal For Front Panel
034	NLA	Not Available	SCREW FOR DOOR KNOB---NA

