


# Maytag DG19CD 01 - CD CONTROL PANEL & CONTROL CENTER



Maytag [Commercial Maytag DG19CD Dryer Parts](#) Parts Diagram 01 - CD CONTROL PANEL & CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
002	203188		Not Available	TIMER ACCESS DOOR (WHT)
003	203188L		Not Available	ACCESS DOOR-ALMOND
004	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
005	NLA		Not Available	MTG. STRAP---NA
006	205423	<a href="#">208883</a>		Coin Box K
007	205423L	<a href="#">208883</a>		Coin Box K
008	205423M	<a href="#">208883</a>		Coin Box K
009	<a href="#">205810</a>			Wire, Ground
010	NLA		Not Available	CIRCUIT BOARD ASSY
011	206794		Not Available	SWITCH (W/NUT)
012	206795		Not Available	COIN DROP METER ASSY
013	206795L		Not Available	COIN DROP METER ASSY
014	NLA		Not Available	COIN DROP METER ASSY
015	Y206800	<a href="#">207766</a>		Transformer

016	206824	<a href="#">W10133335</a>	Relay, Motor
017	<a href="#">206828</a>		Battery
018	<a href="#">211252</a>		Screw, Ground Wire
019	<a href="#">211294</a>	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
020	212276	<a href="#">W10116760</a>	Screw
021	212328	<a href="#">W10139762</a>	Hex Nut, 3/4-27
022	<a href="#">213035</a>		Bolt, Locking
023	213750	<a href="#">W10133266</a>	Cam-Lock
024	<a href="#">214660</a>		Gasket, Control Center
025	<a href="#">215003</a>		Fastener, Panel And Bracket
026	<a href="#">215506</a>		Screw, Control Panel Overlay
027	215510	Not Available	SUPPORT, PC BOARD
028	215515	Not Available	COVER, DISPLAY
029	215517	<a href="#">W10131113</a>	Push Button
030	<a href="#">215526</a>		Screw, Circuit Board
031	215527	<a href="#">W10140652</a>	Screw, 6-20 X 1/2
032	Y305191	Not Available	TOP COVER-WHITE
033	NLA	Not Available	TOP COVER-ALMOND
034	NLA	Not Available	TOP COVER-HARVEST WHEAT
035	NLA	Not Available	CONTROL COVER (WHT)
036	NLA	Not Available	CONTROL COVER ASSY---NA
037	NLA	Not Available	CONTROL COVER ASSY
039	NLA	Not Available	WIRE HARNESS
040	NLA	Not Available	WIRE HARNESS
041	<a href="#">306694</a>		Backup Plate With Switch
042	NLA	Not Available	BACK BRACKET, CONTROL PANEL
043	NLA	Not Available	BACK BRACKET FOR CONTROL PANEL
044	NLA	Not Available	BACK BRACKET FOR CONTROL PANEL
045	NLA	Not Available	CONTROL PANEL
046	<a href="#">910181</a>		Lockwasher, Terminal Block
047	<a href="#">910309</a>		Washer, Mounting Strap
048	<a href="#">912077</a>		Locknut, Reader Harness

