


Maytag DG19CS 08 - CONTROL CENTER (SERIES 02)



Maytag [Commercial Maytag DG19CS Dryer Parts](#) Parts Diagram 08 - CONTROL CENTER (SERIES 02)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	305870			Timer Motor
002	305796			Timer
"	305800			Wire Harness For Timer
"	305813			Part Not Available Part Not Used
003	314333			Timer Mounting Bracket
"	NLA		Not Available	INSTRUCTION LABEL
004	315277			Screw
005	910708	488234		Screw 8-32 X 1/4
006	314546			Wheel, Index
007	Y305799			Bypass Switch For Heater
008	305798		Not Available	BYPASS SWITCH FOR MOTOR
009	314332			Spring, Actuator
010	314339			Switch And Slider Bracket
011	Y052634	701719		Nut, Hex
012	314337	33002968		Slider

013	NLA	Not Available	HELICAL SPRING ----N
014	314548	33002967	Actuator, Switch
015	211790		Lock Ring For Timer Shaft
016	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
017	211065		Spring, Index Wheel
018	Y312270		Clip, Spring Retainer
019	314331		Spring, Torsion Return
020	314335		Peg, Tine Adjustment
021	211168	W10139210	Screw, 8-18 X 5/16
022	306104		Actuator Switch Kit
023	314547	Y308109	Slide And Adj. Return Bracket
024	305800		Wire Harness For Timer
"	NLA	Not Available	MAIN WIRE HARNESS
025	305797		Torsion Timer Assembly Complete

