


# Maytag DG19CS 13 - DOOR



24

Maytag [Commercial Maytag DG19CS Dryer Parts](#) Parts Diagram 13 - DOOR  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	FRONT PANEL (WHT)
002	212982	<a href="#">22001650</a>		Fastener, Spring
003	<a href="#">Y310376</a>			Clip, Door Switch Harness
004	NLA		Not Available	SCREW, DOOR KNOB
005	<a href="#">Y304575</a>	<a href="#">W10169313</a>		Switch-Dor
"	<a href="#">Y305753</a>	<a href="#">W10169313</a>		Switch-Dor
006	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
007	<a href="#">Y313910</a>			Clip, Door Liner To Outer Panel
008	<a href="#">306436</a>			Door Latch Kit--W
009	<a href="#">Y313911</a>			Door Strike Retainer
010	NLA		Not Available	KNOB & SCREW
011	NLA		Not Available	(ALM)
"	<a href="#">Y306668</a>			DOOR (WHT)
012	NLA		Not Available	INNER DOOR W/KNOB
013	NLA		Not Available	ACCESS DOOR (WHITE)
014	<a href="#">314077</a>			Door Seal

015	Y304577	<a href="#">33001230</a>	Hinge, Door
016	<a href="#">204439</a>		Screw And Fstner Assembly
017	<a href="#">Y313907</a>		Fastener, Twin
018	212949	<a href="#">22001866</a>	Screw, Relay
019	NLA	Not Available	BUSHING, ACCESS STUD
020	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
021	<a href="#">314286</a>		Seal For Front Panel
022	NLA	Not Available	GAS IGNITION LABEL
023	<a href="#">Y313927</a>		INSTRUCTION LABEL
024	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>