


# Maytag DG21CT 08 - FRONT PANEL & DOOR ASSEMBLY



Maytag Commercial Maytag DG21CT Dryer Parts Parts Diagram 08 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">204439</a>			Screw And Fstner Assembly
002	212949	<a href="#">22001866</a>		Screw, Relay
003	212982	<a href="#">22001650</a>		Fastener, Spring
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	<a href="#">Y304575</a>	<a href="#">W10169313</a>		Switch-Dor
006	Y304577	<a href="#">33001230</a>		Hinge, Door
007	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
008	NLA		Not Available	FRONT PANEL-WHITE
009	<a href="#">304965</a>			Door Complete-White
010	NLA		Not Available	INNER DOOR WITH KNOB & SCRE
011	NLA		Not Available	KNOB AND SCREW
012	<a href="#">Y310376</a>			Clip, Door Switch Harness
013	NLA		Not Available	BUSHING FOR ACCESS STUD
014	NLA		Not Available	SCREW----NA
015	<a href="#">312360</a>			Sleeve, Access Panel Stud

015	<a href="#">312909</a>		Part Not Used
016	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION
017	<a href="#">Y313907</a>		Fastener, Twin
018	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
019	<a href="#">Y313911</a>		Door Strike Retainer
020	Y313912	<a href="#">306436</a>	Door Latch Kit--W
021	<a href="#">Y313927</a>		INSTRUCTION LABEL
022	Y313946	Not Available	DOOR PANEL-WHITE
023	<a href="#">Y313947</a>		Gasket For Window
024	<a href="#">Y314025</a>		Latch For Access Door
025	<a href="#">Y314062</a>		Screw, Door Hinge And Panel
026	<a href="#">314077</a>		Door Seal
027	NLA	Not Available	GAS IGNITION LABEL
028	<a href="#">314286</a>		Seal For Front Panel
029	NLA	Not Available	SCREW FOR DOOR KNOB--- NA

