


Maytag DG21CT 10 - TUMBLER FRONT, LINT SCREEN & RETAINER



Maytag [Commercial Maytag DG21CT Dryer Parts](#) Parts Diagram 10 - TUMBLER FRONT, LINT SCREEN & RETAINER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y055978			Rubber Adhesive, 2 Oz Tube
002	204439			Screw And Fstner Assembly
003	204807			Ground Wire, Supp. Plte To Top Cover
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	213007			Xfor Cabinet See Cabinet, Back
006	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
007	Y303390		Not Available	LINT SCREEN
008	Y303391	33303391		Thermostat, Cycling
009	303392			Thermostat, Cycling
010	Y303786		Not Available	LINT SCREEN WITH RETAINER
011	Y303815	33001231		Front- Tumbler
012	Y303836			Blower Wheel Assembly And Clamp
013	NLA		Not Available	OUTLET GRID AND DUCT

014	Y304384	33001003	Screen, Lint
015	Y304810	Not Available	OUTLET DUCT ASSEMBLY---S
016	310557		Washer
017	NLA	Not Available	HARNESSE CLIP
018	Y312901		Seal, Housing Cover
019	312940	306508	Tumbler Bearing Kit ----W
020	312941	306508	Tumbler Bearing Kit ----W
021	Y312961	W10116751	Screw
022	312967		Clamp, Blower Housing
023	Y313541	33313541	Seal- Tumbler
024	NLA	Not Available	GRID FOR OUTLET DUCT
025	Y313561		Screw----NA
026	Y313794	Not Available	OUTLET GRID AND DUCT ---S
027	Y313795		Guide For Lint Screen
028	Y313796		Lint Seal
029	410233	9703438	Ring-Retrn

