


Maytag DG22CA 01 - FRONT VIEW



Maytag Commercial Maytag DG22CA Dryer Parts Parts Diagram 01 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	204439			Screw And Fstner Assembly
003	204445			Screw And Fastener Assembly
004	210684			Foot, Adjustable Leg
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	213007			Xfor Cabinet See Cabinet, Back
007	NLA		Not Available	ACCESS DOOR (WHITE)
008	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
009	NLA		Not Available	NAME PLATE ON CONTROL PANEL
010	Y304579	Y306668		DOOR (WHT)
011	NLA		Not Available	SPACER ASSEMBLY
012	NLA		Not Available	FRONT PANEL - DG MODELS
013	Y305087	22003544		Adjustable Leg W/Foot And Nut

014	Y305190	307104	Top Cover Assembly
015	NLA		Not Available CABINET-WHITE
016	NLA		Not Available KNOB AND SCREW
017	Y310632	1163839	Screw
018	310933	33002194	Nut, Speed
019	Y313559		Screw
020	Y313908		DOOR PANEL-WHITE
021	NLA		Not Available TOP COVER PLATE
022	NLA		Not Available SCREW

