


# Maytag DG22CA 04 - FRONT PANEL & DOOR ASSEMBLY



Maytag Commercial Maytag DG22CA Dryer Parts Parts Diagram 04 - FRONT PANEL & DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">204439</a>			Screw And Fstner Assembly
002	212949	<a href="#">22001866</a>		Screw, Relay
003	212982	<a href="#">22001650</a>		Fastener, Spring
004	NLA		Not Available	ACCESS DOOR (WHITE)
005	<a href="#">Y304575</a>	<a href="#">W10169313</a>		Switch-Dor
006	Y304577	<a href="#">33001230</a>		Hinge, Door
007	Y304579	<a href="#">Y306668</a>		DOOR (WHT)
008	NLA		Not Available	FRONT PANEL - DG MODELS
009	<a href="#">Y305753</a>	<a href="#">W10169313</a>		Switch-Dor
010	NLA		Not Available	INNER DOOR WITH KNOB & SCRE
011	NLA		Not Available	KNOB AND SCREW
012	<a href="#">306436</a>			Door Latch Kit-W
013	<a href="#">Y310376</a>			Clip, Door Switch Harness
014	NLA		Not Available	BUSHING FOR ACCESS STUD

015	NLA	Not Available	SCREW---NA
016	<a href="#">312369</a>		Sleeve, Access Panel Stud Part Not Used
017	<a href="#">Y313340</a>		LABEL, LINT SCREEN INSTRUCTION
018	<a href="#">Y313907</a>		Fastener, Twin
019	<a href="#">Y313908</a>		DOOR PANEL-WHITE
020	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
021	<a href="#">Y313911</a>		Door Strike Retainer
022	<a href="#">Y313927</a>		INSTRUCTION LABEL
023	<a href="#">Y314025</a>		Latch For Access Door
024	<a href="#">Y314062</a>		Screw, Door Hinge And Panel
025	<a href="#">314077</a>		Door Seal
026	NLA	Not Available	GAS IGNITION LABEL
027	<a href="#">314286</a>		Seal For Front Panel
028	NLA	Not Available	SCREW FOR DOOR KNOB--- NA

