


DE-DG22CA-CS-CT

**DOOR, TUMBLER, TUMBLER FRONT & BACK
SERIES 05**



- 3-6656 Outlet duct and grid assembly - Beige
 - 3-6657 Outlet duct and grid assembly - Beige - includes the 3-12964 outlet duct - outer half
 - 3-6660 Tumbler back with felt seal - Ivory
 - 3-6663 Tumbler with baffles - Ivory
 - 3-6665 Lint screen - Beige
 - *3-6668 Door complete with Beige inner door - less knob - White
 - *3-6668L Door complete with Beige inner door - less knob - Almond
 - *3-6668M Door complete with Beige inner door - less knob - Harvest Wheat
 - 3-6670 Tumbler front assembly - Ivory
 - *3-6676 Inner door with knob and screw - Beige
 - 3-14802 Tumbler less baffles - Ivory
 - 3-14803 Baffle - short - Beige
 - 3-14804 Baffle - tall - Beige
- *The door assembly parts are for the DE-DG22CA only.

Maytag [Commercial Maytag DG22CS Dryer Parts](#) Parts Diagram 09 - DOOR, TUMBLER, TUMBLER FRONT & BACK
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	306656		Not Available	OUTLET DUCT & GRID ASSEMBLY
002	306657		Not Available	OUTLET DUCT & GRID
003	Y306660	33001106		Back, Tumbler
004	306663		Not Available	TUMBLER W/BAFFLES
005	Y306665	33001003		Screen, Lint
006	Y306668			DOOR (WHT)
007	NLA		Not Available	TUMBLER FRONT----NA
008	NLA		Not Available	INNER DOOR WITH KNOB
009	314802		Not Available	TUMBLER W/OUT BAFFLES
010	314803	33001012		Baffle
011	314804	33001004		Baffle, Tall