


# Maytag DG24CA 01 - FRONT VIEW



Maytag [Commercial Maytag DG24CA Dryer Parts](#) Parts Diagram 01 - FRONT VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
002	<a href="#">204439</a>			Screw And Fstner Assembly
003	<a href="#">204445</a>			Screw And Fastener Assembly
004	212276	<a href="#">W10116760</a>		Screw
005	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
006	NLA		Not Available	ACCESS DOOR (WHITE)
007	NLA		Not Available	ACCESS DOOR-ALMOND
008	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
009	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
010	NLA		Not Available	KNOB AND SCREW
011	NLA		Not Available	FRONT PANEL-WHITE
012	NLA		Not Available	FRONT PANEL-ALMOND
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
017	<a href="#">Y305086</a>			Adjustable Leg And Nut

018	Y305190	<a href="#">307104</a>	Top Cover Assembly
019	NLA	Not Available	TOP COVER-ALMOND
020	NLA	Not Available	TOP COVER-HARVEST WHEAT
021	NLA	Not Available	CONSOLE-WHITE
022	NLA	Not Available	CONSOLE-ALMOND
023	NLA	Not Available	CONSOLE-HARVEST WHEAT
024	NLA	Not Available	CABINET-WHITE
025	NLA	Not Available	CABINET-ALMOND
026	NLA	Not Available	CABINET-HARVEST WHEAT
027	<a href="#">Y306668</a>		DOOR (WHT)
028	NLA	Not Available	DOOR-ALMOND
029	NLA	Not Available	DOOR-HARVEST WHEAT
030	Y310632	<a href="#">1163839</a>	Screw
031	<a href="#">Y313908</a>		DOOR PANEL-WHITE
032	NLA	Not Available	DOOR PANEL-ALMOND
033	NLA	Not Available	DOOR PANEL-HARVEST WHEAT
034	<a href="#">Y314137</a>		Foot, Rubber

