


Maytag DG24CT 02 - CT CONTROL PANEL/TIMER



Maytag Commercial Maytag DG24CT Dryer Parts Parts Diagram 02 - CT CONTROL PANEL/TIMER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	NLA		Not Available	MTG. STRAP---NA
003	NLA		Not Available	ACCESS DOOR (WHITE)
004	NLA		Not Available	ACCESS DOOR-ALMOND
005	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
006	NLA		Not Available	ACCESS DOOR (WHITE)
007	NLA		Not Available	ACCESS DOOR-ALMOND
008	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
009	NLA		Not Available	HARNES FOR TICKET CONTROL
010	NLA		Not Available	OUTER CASE-WHITE
011	NLA		Not Available	OUTER CASE-ALMOND
012	NLA		Not Available	OUTER CASE-HARVEST WHEAT
013	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

014	212276	W10116760	Screw
015	213089		Knob For Timer
016	214660		Gasket, Control Center
017	214878		Latch For Access Door
018	NLA	Not Available	TIMER MOTOR
019	NLA	Not Available	MAIN WIRE HARNESS - DG
022	307142		Timer With Knob And Pin
023	Y312300		Groov-Pin
024	910309		Washer, Mounting Strap

