


Maytag DG24CT 05 - REAR VIEW



Maytag Commercial Maytag DG24CT Dryer Parts Parts Diagram 05 - REAR VIEW

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052740	62739		Nut, Lock
002	Y201808			Converter
003	204439			Screw And Fstner Assembly
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
005	211881			Grommet, Cord Part Not Used-Gas Models Only
006	212276	W10116760		Screw
007	213007			Xfor Cabinet See Cabinet, Back
008	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
009	301548			Clamp, Ground Wire
010	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
011	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
012	NLA		Not Available	SCREW & WASHER ASSY.

013	NLA		Not Available	FRONT PANEL-WHITE
014	NLA		Not Available	FRONT PANEL-ALMOND
015	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
016	NLA		Not Available	FRONT PANEL-WHITE
017	NLA		Not Available	FRONT PANEL-ALMOND
018	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
019	Y305086			Adjustable Leg And Nut
020	305168	33002916		Power Cord, Canadian 240V
021	Y305191		Not Available	TOP COVER-WHITE
022	NLA		Not Available	TOP COVER-ALMOND
023	NLA		Not Available	TOP COVER-HARVEST WHEAT
024	NLA		Not Available	CONSOLE-WHITE
025	NLA		Not Available	CONSOLE-ALMOND
026	NLA		Not Available	CONSOLE-HARVEST WHEAT
027	NLA		Not Available	CABINET-WHITE
028	NLA		Not Available	CABINET-ALMOND
029	NLA		Not Available	CABINET-HARVEST WHEAT
030	NLA		Not Available	CONTROL COVER (WHT)
031	NLA		Not Available	CONTROL COVER ASSY----NA
032	NLA		Not Available	CONTROL COVER ASSY
034	311155			Ground Wire And Clamp
041	Y312905		Not Available	COVER, TERMINAL
042	Y312951		Not Available	ACCESS COVER, BACK
043	313122			Screw - Baffle To Tumbler
044	Y313559			Screw
046	Y314137			Foot, Rubber

