


# Maytag DG26CA 01 - FRONT VIEW - CA MODELS

SECTION: FRONT VIEW  
MODEL: DE-DG26CA



Issue Date: 11/90

6

Maytag Commercial Maytag DG26CA Dryer Parts Parts Diagram 01 - FRONT VIEW - CA MODELS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">307104</a>			Top Cover Assembly
"	NLA		Not Available	(ALM)
002	212276	<a href="#">W10116760</a>		Screw
"	NLA		Not Available	CONSOLE (WHT)
003	NLA		Not Available	CABINET (WHT)
"	Y310632	<a href="#">1163839</a>		Screw
004	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
005	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
006	<a href="#">Y305086</a>			Adjustable Leg And Nut
007	<a href="#">Y314137</a>			Foot, Rubber
008	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
009	<a href="#">204439</a>			Screw And Fstner Assembly
010	NLA		Not Available	ACCESS DOOR - DG (WHT)
011	<a href="#">307998L</a>			Front Panel----NA
"	NLA		Not Available	FRONT PANEL (WHT)

012	308061	Not Available	DOOR ASSY. COMPLETE (WHT)
"	NLA	Not Available	(ALM)
013	<a href="#">314946</a>		Handle White
"	<a href="#">314972</a>		Handle Door ALM
"	NLA	Not Available	(H. WHEAT)
014	<a href="#">204445</a>		Screw And Fastener Assembly

