


Maytag DG26CT 01 - FRONT VIEW - CT MODELS

SECTION: FRONT VIEW
MODEL: DE-DG26CT



Maytag Commercial Maytag DG26CT Dryer Parts Parts Diagram 01 - FRONT VIEW - CT MODELS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	307105		Not Available	COVER, TOP ASSY. (WHT)
"	NLA		Not Available	TOP COVER ASSY ALM
002	NLA		Not Available	ACCESS DOOR (WHT)
003	212276	W10116760		Screw
"	NLA		Not Available	CONTROL COVER (WHT)
004	NLA		Not Available	OUTER CASE (WHT)
005	Y052740	62739		Nut, Lock
006	NLA		Not Available	ACCESS DOOR (WHT)
007	214878			Latch For Access Door
008	214660			Gasket, Control Center
009	910309			Washer, Mounting Strap
010	NLA		Not Available	MTG. STRAP---NA
011	NLA		Not Available	CABINET (WHT)
"	Y310632	1163839		Screw
012	213007			Xfor Cabinet See Cabinet, Back
				BASE ASSY / UPPER P

013	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
014	Y305086		Adjustable Leg And Nut
015	Y314137		Foot, Rubber
016	NLA	Not Available	ACCESS DOOR (WHT)
017	307998L		Front Panel---NA
"	NLA	Not Available	FRONT PANEL (WHT)
018	308061	Not Available	DOOR ASSY. COMPLETE (WHT)
"	NLA	Not Available	(ALM)
019	314946		Handle White
"	314972		Handle Door ALM
"	NLA	Not Available	(H. WHEAT)
020	204445		Screw And Fastener Assembly

the laundry company[®]

the laundry company[®]

the laundry company[®]