


Maytag DG26CT 04 - CONTROL CENTER - CT MODELS

SECTION: CT CONTROL CENTER
 MODEL: DE-DG26CT



Maytag [Commercial Maytag DG26CT Dryer Parts](#) Parts Diagram 04 - CONTROL CENTER - CT MODELS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	ACCESS DOOR (WHT)
002	214878			Latch For Access Door
003	NLA		Not Available	WIRE HARNESS
004	NLA		Not Available	HARNESS, TICKET CONTROL
005	NLA		Not Available	OUTER CASE (WHT)
006	NLA		Not Available	ACCESS DOOR (WHT)
007	214660			Gasket, Control Center
008	NLA		Not Available	MTG. STRAP---NA
009	910309			Washer, Mounting Strap
010	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
011	Y052740	62739		Nut, Lock
012	213089			Knob For Timer
"	Y312300			Groov-Pin
013	NLA		Not Available	TIMER MOTOR
"	Y303801		Not Available	TIMER WITH KNOB AND PIN

