


Maytag DG27CT 10 - THERMOSTATS

SECTION: THERMOSTATS
 MODEL: DE-DG27CA-CS-CT



Issue Date: 10/90

38

Maytag [Commercial Maytag DG27CT Dryer Parts](#) Parts Diagram 10 - THERMOSTATS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
002	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	303392			Thermostat, Cycling
003	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	306604			Cut-Off, Thermal Part Not Used
004	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	306966			Thermostat, Multi-Temp Part Not Used Mdg26ct-MN Only
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	306967			Thermostat, Multi-Temp Part Not Used Mde26ct-MN Only
006	Y313561			Screw---NA
"	315122		Not Available	COVER, THERMOSTAT PART NOT USED (MDE

