


Maytag DG30CA 01 - FRONT VIEW-DOOR OPEN



Maytag Commercial Maytag DG30CA Dryer Parts Parts Diagram 01 - FRONT VIEW-DOOR OPEN
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	GULMITE WRENCH No.8
002	NLA		Not Available	SCREW, No.5-40 X 3/8
003	213966	3400014		Screw
004	Y330064			Pilot Light
005	NLA		Not Available	LEVELING LEG
006	Y330077			Door Switch
007	Y330079		Not Available	SWITCH, PUSH-TO-START
008	Y330080		Not Available	SPIDER & SHAFT ASSEMBLY
009	330081			Timer - CA 60 Minutes
010	Y330082	330081		Timer - CA 60 Minutes
011	Y330087			Drum Assembly Complete
012	NLA		Not Available	DOOR-WHITE
013	NLA		Not Available	DOOR-HAVEST WHEAT
014	NLA		Not Available	FRONT PANEL-WHITE
015	NLA		Not Available	FRONT PANEL-ALMOND
				FRONT PANEL HARVEST

016	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
017	NLA		Not Available	HINGE FOR DOOR
018	Y330102			FRONT PANEL-WHITE
019	NLA		Not Available	FRONT PANEL-ALMOND
020	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
021	Y330103			Lock
022	NLA		Not Available	FRONT PANEL-WHITE
023	330108L		Not Available	FRONT PANEL-ALMOND
024	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
025	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
026	NLA		Not Available	HANDLE & PIN KIT
027	NLA		Not Available	DOOR-WHITE
028	NLA		Not Available	DOOR-ALMOND
029	NLA		Not Available	DOOR-HARVEST WHEAT
030	331014	8281196		Screw
031	NLA		Not Available	SCREW - HANDLE TO DOOR
032	331032	61002031		Screw, Handle
033	331036			Washer-Front Panel Screws
034	331041			Button-Push-To-Start Switch
035	331055			Gasket For Door
036	NLA		Not Available	GLASS FOR LOADING DOOR
037	331061			Knob For Temperature Contro
038	331064		Not Available	MAGNET FOR DOOR HANDLE
039	331071		Not Available	STRIKE PLATE FOR DOOR
040	331083		Not Available	SUPPORT FOR DOOR GLASS
041	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
042	NLA		Not Available	TRIM STRIP-LOWER FRONT PANE
043	NLA		Not Available	TRIM BAR FOR UPPER PANEL
044	NLA		Not Available	BUMPER STRIP FOR DOOR
045	NLA		Not Available	POLE BLOCK FOR DOOR MAGNET
046	331101		Not Available	BEZEL FOR TIMER-ACCUMULATOR
047	NLA		Not Available	INSTRUCTION PLATE (CA)
048	NLA		Not Available	HINGE RIVET
049	NLA		Not Available	DOWEL PIN FOR HANDLE
050	331151			Lever-Temperature Control
051	331185			Hinge Pin For Door
052	911852	486009		Lockwasher