


Maytag DG30CA 06 - SWITCH, TEMPERATURE & TERMINAL BLOCK

MODEL DG30CA-CM-CMD-CT
DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK
 DG30CMD-CT-ORIGINAL & SERIES 01
 DG30CA-CM-ORIGINAL-SERIES 01 & SERIES 02



Maytag Commercial Maytag DG30CA Dryer Parts Parts Diagram 06 - SWITCH, TEMPERATURE & TERMINAL BLOCK
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	NLA		Not Available	CAGE NUT
005	212220	213501		Screw, No.6-20 X 1-1/8 Inch
006	212951			Screw, No.6-32 X 1/4 Inch
007	NLA		Not Available	CLIP - ACTUATOR TO CABINET
008	Y330077			Door Switch
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	Y330087			Drum Assembly Complete
011	Y330087			Drum Assembly Complete
012	Y330092			Terminal Block
013	NLA		Not Available	VAULT ASSEMBLY
014	NLA		Not Available	SCREW - BRACKET TO VAULT
015	331012	400022-1		Screw

016	331014	8281196		Screw
017	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
018	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
019	331058			Grommet-Temp. Control Tubin
020	331061			Knob For Temperature Contro
021	NLA		Not Available	MOUNTING PLATE-TEMP.CONTROL
022	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
023	NLA		Not Available	DRUM ROD
024	NLA		Not Available	SPACER - TEMP CONTROL COVER
025	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
026	NLA		Not Available	SCREW-TEMP CONTROL LEVER
027	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
028	331151			Lever-Temperature Control
029	NLA		Not Available	TWIN FASTENER WITH SCREWS

