


Maytag DG30CM 07 - SWITCH, TEMPERATURE & TERMINAL

MODEL DG30CA-CM-CMD-CT
DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK
 DG30CMD-CT-ORIGINAL & SERIES 01
 DG30CA-CM-ORIGINAL-SERIES 01 & SERIES 02



Maytag Commercial Maytag DG30CM Dryer Parts Parts Diagram 07 - SWITCH, TEMPERATURE & TERMINAL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	NLA		Not Available	CAGE NUT
005	212220	213501		Screw, No.6-20 X 1-1/8 Inch
006	212951			Screw, No.6-32 X 1/4 Inch
007	NLA		Not Available	CLIP - ACTUATOR TO CABINET
008	Y330077			Door Switch
009	Y330078			Cool-Down Bypass Switch
010	Y330083		Not Available	CONTROL, TEMPERATURE
011	Y330087			Drum Assembly Complete
012	Y330092			Terminal Block
013	NLA		Not Available	VAULT ASSEMBLY
014	NLA		Not Available	SCREW - BRACKET TO VAULT
015	331012	400022-1		Screw

016	331014	8281196		Screw
017	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
018	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
019	331058			Grommet-Temp. Control Tubin
020	331061			Knob For Temperature Contro
021	NLA		Not Available	MOUNTING PLATE-TEMP.CONTROL
022	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
023	NLA		Not Available	DRUM ROD
024	NLA		Not Available	SPACER - TEMP CONTROL COVER
025	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
026	NLA		Not Available	SCREW-TEMP CONTROL LEVER
027	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
028	331151			Lever-Temperature Control
029	NLA		Not Available	TWIN FASTENER WITH SCREWS

