


Maytag DG30CT 04 - CMD TIMER ACCUMULATOR-SINGLE COIN



- 3-30112 Switch for timer motor
- 3-30113 Timer motor
- 3-30116 Timing cam kit - 7-1/2 minutes - 8 pins on cam
- 3-30117 Timing cam kit - 10 minutes - 6 pins on cam
- 3-30145 Timer accumulator complete (.10) - single coin - CMD
- 3-30162 Switch for time delay
- 3-30163 Coin handling mechanism
- 3-30164 Meter plate assembly
- 3-30165 Coin retainer spring and screw kit
- 3-31118 Coil spring for pawl
- 3-31121 Coil spring for detent arm
- 3-31122 Index lever and switch actuator
- 3-31147 Coil spring for coin carrier return

the laundry company®

Maytag [Commercial Maytag DG30CT Dryer Parts](#) Parts Diagram 04 - CMD TIMER ACCUMULATOR-SINGLE COIN
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	330112			Switch For Actuator
002	330113			Timer Motor
003	330116		Not Available	TIMING CAM - 8 PINS
004	330117		Not Available	TIMING CAM - 6 PINS
005	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
006	Y330162			Switch For Time Delay
007	NLA		Not Available	COIN HANDLING MECHANISM
008	NLA		Not Available	METER PLATE ASSEMBLY
009	Y330165			Retainer Spring And Screw Kit
010	NLA		Not Available	COIL SPRING FOR PAWL
011	NLA		Not Available	COIL SPRING FOR DETENT ARM
012	NLA		Not Available	INDEX LEVER-SWITCH ACTUATOR
013	NLA		Not Available	COIL SPRING F/CARRIER RETUR